

FIREDTV FloppyDTV

FireDTV Transponder Update Tool for
Windows MCE and Vista MCE


Version 1.0 - 071122

General description

The FireDTV MCE Transponder Updater helps you in updating or changing the transponder settings used by the FireDTV MCE device driver software.

Updating the transponder settings


To update the transponder setting run the *FireDTV MCE Transponder Updater* from the FireDTV – Tools folder in the start menu.



Open the 'Transponder configuration file' (config.ini) from the MCE settings folder located in "c:\program files\FireDTV\MCE settings".

Select which transponder type is appropriate for your configuration - select '**Satellite**' or '**Cable**'.

From the 'Transponder Settings' list select the configuration you want to store in the registry and click '**Store to Registry**' to save the new settings into the registry.



ATTENTION: you old settings will be overwritten and therefore lost.

NOTE: Under Windows Vista you may need to run the tool with administrator privileges.